

N = zero  
 L = life wire  
 LS = Life switch wire (for non continue)  
 (for continue on connect "LS" to "L")  
 GR= ground (earth wire)

